



INSTALLATION MANUAL


- 1** Below the tray, connect the component up to the faucet body.



- 2** The cold water and hot water hoses pass through the nuts. Turn the nuts clockwise to fix the faucet.



- 3** Connect the hot and cold water hoses to the cold and hot water outlets respectively.



- 4** Make sure all the connections are fully connected. Turn on the switches and clear the impurities if any. Turn the handle outward to open, the greater the angle, the greater the flow, vice versa. When the handle is opened outwards, the amount of hot water supply increases with left-handle adjustment; the amount of cold water supply increases with right-handled adjustment.

